

DPVR-4D Pro User's Manual

◆ Activation method

- Press and hold the power button for 3 seconds until the L.A.B symbol appears.

Home screen interface

※ Contents are subject to change.



User display, login or logout button

app store Go to the app store. You can download games, all-you-can-see CH and other apps.

local playback A list of videos stored on internal storage, SD card, and external HDD can be viewed by storage.

storage All files stored in all storage areas are displayed and those that are not needed can be deleted.

Volume Go to the volume control screen

Brightness Go to brightness adjustment screen

Bluetooth Go to the Bluetooth settings screen
■ Simultaneous connection to Bluetooth and other Bluetooth-enabled devices is possible.

Controller Go to the controller settings screen

Wi-Fi Go to the Wi-Fi settings screen

Return Return screen to front position


Language Switching system language (Japanese or English)

Cache Delete cache (temporary files)

Auto sleep Go to the auto sleep setting screen

Tutorial Go to the tutorial (instruction) screen for this device.

◆ How to update and initialize online

- ① Move your eye to the icon  from the [Apps List] at the bottom of the home screen, and click on the device touch panel→Apps are launched.
- ② Place your eye on the center of the circle and click on the device touch panel.
If there is a firmware update, the installation will start, and if the firmware is already the latest version, the message [The current version is the latest] will appear.
· If you wish to initialize the unit, select Factory Reset from the upper right corner of the update screen.
Please note that Wi-Fi, applications, etc. will also be initialized.

◆ Video Playback Method

◇ About Streaming Playback

After selecting the thumbnail of the video you wish to view, select the play button on the details screen to watch it.

◇ About Local Playback

Select the thumbnail of the video you want to watch to watch it.

◇ Playback screen

Tap the touch panel while watching a video to display the menu.

The center menu allows you to "Play," "Pause," "Change playback position with the seek bar," "Go back to the beginning of the playback file (00:00:00)," and the side menu allows you to adjust "Volume," "Brightness," "Zoom," and "Subtitle Settings." Select "Yes" to exit.

To take full advantage of the DPVR-4D Pro features, we recommend registering as a member of the L- POINT website.

Click here to register as a member.

 https://www.lpeg.jp/en_point/pass_remem.php



After the head mount is turned on and the Home screen appears, move the cursor to the Login button on the upper right side of the screen (⑤ in the figure below) and tap the touchpad to go to the login screen.

Please log in to the L-POINT site by entering the ID and password with which you registered as a member.

If you register as an L-POINT member (free of charge) on your smartphone or PC and charge points to the corresponding account, you can purchase videos after logging in on your device (DPVR-4D series).

· VR World : It distributes videos in various genres such as music, art, culture, and tourism.

◆ For more information on each app, please refer to the following.

· VeeR
<https://veer.tv/>

· YouTube
<https://www.youtube.com/>

· Browser
This is an application for online search.